
»Wheels »Car Care

» Wheel & Tire Center

» Network Links

»Motorcycle Reviews
»Motorcycle Classifieds
»ATV Reviews
»Jetski Reviews
»Snowmobile Reviews
»E.I.Cruiser Wheels
»F.J.Cruiser Parts

It appears you have not yet registered with our community. To post, access all available content, and enjoy the benefits of being a member, please click here...



I did some research through <u>FJ Cruiser Forums</u>, and <u>Toyota120.com</u> and the same name kept coming up time and time <u>4Crawler Off Road</u>. A few emails exchanged and I had ordered a 1.25" UHMW body lift kit for myself, and a 1.5" UHMW friend.

Both kits included -

8 x Ultimate Body Lift Blocks Heavy duty hardware Steering shaft spacer Radiator drop brackets

We recieved the kit from Roger in perfect condition and everything was there, so I highly recommend 4Crawler for your

## [SIZE="5"]The Install[/SIZE]

We put Glens truck in the garage. It looked like this to start with



The first step was to find all the body mount loactions, and loosen all the bolts. There is 8 in total, the front ones are lo headlight support, inside little recesses in fornt of the front wheel wells. The photos are of the drivers side ones, the pamirrored.



The second is inside the vehicle, close to the firewall. Remove the door sills, foot rest (drivers side) plastic nut and the I floor covering up and you will expose a rubber grommet about 2in diameter. pul it out and it will expose the top ofthe b

This image has been resized. Click this bar to view the full image.



The 3rd one is next to the rear seat. Fold the base of the seat up against the fornt seats, and from where the child resti floor covering out from under the plastic side trim. The grommet and bolt hole wil be exposed in the corner of the floor.



The last one is accessible from behind the cargo area trim. Remove your jack/tools cover and you will see the grommet passenger side is as easy as removing the inverter trim and it is behind that.



Loosen all the nuts, dont take them off at this stage.

Next take the radiator trim and shroud off the radiator. The trim is removed by the 7 clips.

This image has been resized. Click this bar to view the full image.

Also take the shroud off, by 5 10mm bolts ( 3 on the overflow bottle, 2 on the radiator shroud.) The shroud is held in the it up to dislodge it and lay it against the motor



🦍 This image has been resized. Click this bar to view the full image



At this stage you will also need to remove the front bumper and grille. Stock bumper removal instructions are here For aftermarket bumpers, consult your user manual 😅

For aftermarket bumpers, consult your user manual

For stock bumper-ees, you will need to remove the stell brace behind the front bumper ( 4 14mm nuts on both sides of re-install this 1 set of holes up to align the bumper with the body on your lift.







Next loosen the steering column slip joint located in the engine bay underneath the brake master cyl, accessible via the the drivers side front wheel well. Lossen both bolts located here.

This image has been resized. Click this bar to view the full image.



Climb inside the drivers foot well, and pull the black plastic steering column shroud of as well (4 plastic nuts). This will joint. Take out both 12mm bolts with nuts on them (do not touch the studs) and slide the longer botls in that were supplextension - and do the nuts up a couple of threads. This will allow the steering joint to seperate as you lift the vehicle vehicl



If you have a Man-A-Fre auxillary tank, you will need to pull the filler neck inspection cover off (Rr drivers side wheel w hose clamps that hold the fill neck rubber hosing to the fill neck. This will allow it to slide as you jack the body up.

Now your ready to start lifting the body. One side at a time to avoid anything shifting, take the nuts completely off the

Theres a few ways you can do this part, but the most easy and successful i have done is by using a scissor style jack on block off wood to spread the weight over the wheel well.

This image has been resized. Click this bar to view the full image.



Each wheel you lift from gives you access to 2 body mounts eg. Front Drivers side you can get the front ds mount and t Back drivers side you can access the 3rd ds mount and the rear one.

Crank the jack until you can slide a block in between the vehicle body and the existing factory rubber mounts. Pop the block in, then drop the new bolt (w/ new washer on top side) through and with the existing washer and a new bolt tight



Not the best pic but it should look like

T <- New Bolt 0 <- New washer

---- <- Floor

I <-Body lift block

8 <-existing top rubber body mount

---- <- frame mount

8 <- existing bottom rubber body mount 0 <- existing washer

Q <- new lock nut

The front two mounts have shorter bolts then the back 6 - dont get them mixed up (i did!)

Now carry out this same procedure for the remaining 3 mounts per side.. Jack up, slide new blocks in, jack down, jack  $\iota$ 

Once you have completed one side, finger tightn the nuts you just installed, and head over to the other side where you thing you just did.

Once both sides are completed, torque all nuts to 50ft-lb and you have just installed your new body lift!

Now its time to re-install everything.

The Steering column should have spereated and you will be able to slide the steering column spacer between the rag jo This image has been resized. Click this bar to view the full image.



Tighten it good and then proceed to the steering slip joint at the firewall which you loosened earlier and tighten it back

You can now reinstall all your interior.

The radiator drop brackets are installed by removing the 4 12mm bolts that support the radiator from the front with the TOP



A This image has been resized. Click this bar to view the full image.



Slide the drop brackets in so the hex bolt goes through the rubber mount and the stud through the original support hol them, you may have interference issues with a nut located on the front bib panel. If you do, you can cut it off or install stop you plastic radiator hitting the nut.



Tighten these support brackets and reinstall your fan shroud and overflowe bottle, and double check to make sure your radiator, or shroud.

After you have completed the radiator drop you can re-install your bumper. The stock bumper will align perfectly if you crossmember as mentioned above.

Double check EVERYTHING!!! I had 1.25 on my truck and everything was ok, except the main tank fill hose and come u neck. For some reason the clamp wasnt tight.

Glens PS line from the resorvoir was getting tight with his 1.5in lift so we replaced it. The gas tank skid also has a grou too stretched with a body lift and will need to be modified.

We left our rear bumpers at stock height which left a gap in the plastic corner peice, but both of us dont really care abo something out for it furthur down the road.

Both of us were also happy with the slider gap, means we can use our MAF sliders as steps and brings them off the body

Front bumpers are both stock for now, and the body lifts will be accomodated when we get front bars.

The xfer gear lever is low, and my TT gear know hits the plastic center console in 4L, but glens doesnt (he has the stand

We did these lifts on Saturday and have ben driving the trucks with no problems since.

The finished product

Glenns Before

This image has been resized. Click this bar to view the full image.







Mine After (1.25in)



Sorry if my instructions are a bit confusing or vague, i didnt realise this write up would take so long and i'm supposed to hurry through it!

If you have any questions just shoot me a pm.

Oh - and doing the body lift may be boring for some!



Its a TOYOTA thing - shove your jeep up your A..

## Check Out...

"Casper", my SAC'd and supercharged 08 TT

## NOW FOR SALE, PM ME

Last edited by !Cruzer!; 07-26-2011 at 07:25 PM.



## Re: Body Lift Install W/Pics **Dominic**G Cool! **99999 Demello-Offroad** 951-735-4417 SoCal FJs The Original Airborne Motorhome Join Date: Apr 2006 Member Number: 1647 Location: Afghanistan Posts: 7,990 Blog Entries: 1 양 대 (2 (2 02-03-2009, 02:37 PM Re: Body Lift Install W/Pics mattmainster Forum Superstar Wow....nice. D BajaRack (II) ICON PILAUISERS Intense Fabrication Inc. Join Date: May 2007 Member Number: 11822 SoCal FJ Cruiser Forums Location: Upland, CA Posts: 1,689 20 E G 02-03-2009, 02:38 PM Re: Body Lift Install W/Pics **MudLovingFJ** Very interesting **99999** 2007 Sun Fusion Cruiser 5AT 4X4 SOLD Do it right the first time or don't do it at all. The So-Cal Safari Snorkel Install Guy 14 chicken necks installed to date Join Date: Jan 2007 Member Number: 8945 Location: Somewhere where I don't know where I am. Actually, the OC Posts: 3,763 99 🕶 😂 🕼 **1** 02-03-2009, 02:41 PM Re: Body Lift Install W/Pics **MIKESCRUISER** looks great Check out my RIG http://socalfjcruiserforums.com/foru...read.php?t=218 check out FJ Cruiser shirts http://www.fjcruiserforums.com/forum...ml#post1691957 Join Date: Dec 2007 Member Number: 16266 Location: Socal Posts: 1,880 99 🖫 😂 🔞 **1** 02-03-2009, 02:46 PM Re: Body Lift Install W/Pics rockland

12/31/2011 10:47 AM

those tall FJ's look so cool@

Check out my build. The Warlord

Forum Master

₩₩

Join Date: Jun 2008 Member Number: 20180